



UG65 LoRaWAN Gateway

Quick Start Guide



Welcome

Thank you for choosing Ursalink UG65 LoRaWAN Gateway.

This guide teaches you how to install the UG65 and how to log in the web GUI to configure the device. Once you complete the installation, refer to the Ursalink UG65 User Guide for instructions on how to perform configurations on the device.

Related Documents



This Quick Start Guide only explains the installation of Ursalink UG65 LoRaWAN Gateway. For more functionality and advanced settings, please refer to the relevant documents as below.

Document	Description
Ursalink UG65 Datasheet	Datasheet for the Ursalink UG65 LoRaWAN Gateway.
Ursalink UG65 User Guide	Users can refer to the guide for instruction on how to log in the web GUI, and how to configure all the settings.

The related documents are available on Ursalink website: <https://www.ursalink.com>.

Declaration of Conformity

UG65 is in conformity with the essential requirements and other relevant provisions of the CE, FCC, and RoHS.



For assistance, please contact
Ursalink technical support:
Email: support@ursalink.com
Tel: 86-592-5023060
Fax: 86-592-5023065

Revision History


Date	Doc Version	Description
August 31, 2020	V1.0	Initial version

Contents


1. Packing List.....	4
2. Hardware Introduction.....	5
2.1 Overview.....	5
2.2 Dimensions.....	5
2.3 LED Indicators.....	6
2.4 Reset Button.....	6
3. Hardware Installation.....	7
3.1 SIM Card Installation.....	7
3.2 Ethernet Cable & Power Cable Installation.....	7
3.3 Antenna Installation.....	7
3.4 Gateway Mounting.....	8
3.4.1 Wall Mounting.....	8
3.4.2 Pole Mounting.....	9
4. Access the Web GUI of UG65.....	10
4.1 Web GUI Access via Wi-Fi.....	10
4.2 Web GUI Access via Ethernet Port.....	11
5. Connect UG65 to the Network.....	13
5.1 Configure the WAN Connection.....	13
5.2 Configure the Wi-Fi Connection.....	14
5.3 Configure the Cellular Connection.....	15
6. Packet Forwarder Configuration.....	17
7. Network Server Configuration.....	19
7.1 Connect UG65 to Ursalink Cloud.....	19
7.2 Connect UG65 to Other Platform.....	21

1. Packing List


Before you begin to install the UG65 LoRaWAN Gateway, please check the package contents to verify that you have received the items below.




1 × UG65



1 × Ethernet Cable




1 × DC Jack Power Adapter




1 × Mounting Bracket



Bracket Fixing Screws
& Grounding Screw



Wall Mounting Kits



1 × Warranty Card



1 × LoRa Antenna
(Optional)




If any of the above items is missing or damaged, please contact your Ursalink sales representative.

2. Hardware Introduction


2.1 Overview

A. Front Panel






- ① LED Area
 POWER: Power Indicator
 STATUS: System Indicator
 LoRa: LoRa Indicator
 Wi-Fi: Wi-Fi Indicator
 LTE: Cellular Indicator
 ETH: Ethernet Port Indicator
- ② LoRa Antenna Connector
 (only for external antenna version)

B. Rear Panel



- ③ Bracket Mounting Screws
- ④ SIM Slot
- ⑤ Type-C Port
- ⑥ Ethernet Port (PoE)
- ⑦ Power Connector
- ⑧ Reset Button
- ⑨ Waterproof Silicone
- ⑩ Cable Groove

2.2 Dimensions (mm)



2.3 LED Indicators

LED	Indication	Status	Description
POWER	Power Status	Off	The power is switched off
		On	The power is switched on
STATUS	System Status	Blue Light	Static: the system is running properly
		Red Light	The system goes wrong
LoRa	LoRa Status	Off	Packet Forwarder mode is running off
		Blue Light	Packet Forwarder mode is running well
Wi-Fi	Wi-Fi Status	Off	Wi-Fi is disabled
		Blue Light	Wi-Fi is enabled
LTE	Cellular Status	Off	SIM card is registering or fails to register (or there are no SIM cards inserted)
		Blue Light	Blinking slowly: SIM card has been registered and is ready for dial-up
			Blinking rapidly: SIM card has been registered and is dialing up now
		Static: SIM card has been registered and dialed up successfully	
ETH	Ethernet Port Status	Off	Disconnected
		Blue Light	Static: Connected

2.4 Reset Button

Function	Description	
	STATUS LED	Action
Reset	Static Blue	Press and hold the reset button for more than 5 seconds.
	Static Blue → Rapidly Blinking	Release the button and wait.
	Off → Static Blue	The gateway resets to factory default.


3. Hardware Installation

3.1 SIM Card Installation

! UG65 does not support hot plugging (also called hot swapping). please turn off the power before you insert or take off cards.


- A. Use screwdriver to open the protective cover on the back panel of UG65.
- B. Insert the SIM card into the device according to the direction icon on the device.

Note: If you need to take out the SIM card, press into the SIM card and it will pop up automatically.



3.2 Ethernet Cable & Power Cable Installation


- A. Connect the Ethernet cable and power cable to corresponding interfaces.
- B. Pass two cables through the waterproof silicone and slid into the grooves.
- C. Screw the protective cover back to the device.



UG65 also supports 802.3af standard PoE and can be powered by PoE switch or PoE adapter. When connecting, Ethernet cable of UG65 device side should be installed first, otherwise, PoE devices or gateway may be damaged.

3.3 Antenna Installation

For external antenna version, rotate the antenna into the antenna connector accordingly. The external antenna should be installed vertically always on a site with a good signal.



3.4 Gateway Mounting

The gateway can be mounted to a wall or a pole. Please complete all software configurations before installation.

3.4.1 Wall Mounting

Preparation: mounting bracket, bracket fixing screws, grounding screw, wall plugs, wall mounting screws and other required tools.

1. Before you start, make sure that your SIM card has been inserted, your antennas have been attached and all cables have been installed.

Note: Do not connect device to power supply or other devices.


2. Align the mounting bracket horizontally to the desired position on the wall, use a marker pen to mark four mounting holes on the wall, and then remove the mounting bracket from the wall.

Note: The connecting lines of adjacent points are at right angles.


3. Drill four holes with a depth of 32 mm by using your drill with a 6 mm drill bit on the positions you marked previously on the wall.

4. Insert four wall plugs into the holes respectively.


5. Mount the mounting bracket horizontally to the wall by fixing the wall mounting screws into the wall plugs.



6. Screw the bracket fixing screws to the back panel of device, then hang the device to the mounting bracket on the wall.



7. Screw the grounding screw to fix UG65 to the mounting bracket.



3.4.2 Pole Mounting

Preparation: mounting bracket, bracket fixing screws, hose clamp and other required tools.


1. Before you start, make sure that your SIM card has been inserted, your antennas have been attached and that all cables have been installed.

Note: Do not connect device to power supply or other devices.

2. Loosen the hose clamp by turning the locking mechanism counter-clockwise.


3. Straighten out the hose clamp and slide it through the rectangular rings in the mounting bracket, wrap the hose clamp around the pole.

4. Use a screwdriver to tighten the locking mechanism by turning it clockwise.



5. Screw the bracket fixing screws to the back panel of device, then hang the device to the mounting bracket on the pole.

6. Screw the grounding screw to fix UG65 to the mounting bracket.



4. Access the Web GUI of UG65

Ursalink UG65 provides web-based configuration interface for management. If this is the first time you configure the gateway, please use the default settings below:

ETH IP Address: **192.168.23.150**

Wi-Fi IP Address: **192.168.1.1**


Wi-Fi AP: **Ursalink_*******

Username: **admin**

Password: **password**

4.1 Web GUI Access via Wi-Fi


- Choose the wireless network Ursalink_***** from the list and click Connect.
- Open a Web browser on your PC (Chrome is recommended) and type in the IP address 192.168.1.1 to access the web GUI.
- Enter the username and password, click “Login”.



If you enter the username or password incorrectly more than 5 times, the login page will be locked for 10 minutes.

D. When you log in with the default username and password, you will be asked to change password. It's suggested that you change the password for the sake of security. Click “Cancel” button if you want to modify it later.


E. After you log in the Web GUI, you can view system information and perform configuration of the gateway.




4.2 Web Access via Ethernet Port

Connect PC to UG65 ETH port directly or through PoE adapter. The following steps are based on Windows 10 operating system for your reference.

A. Go to “Control Panel” → “Network and Internet” → “Network and Sharing Center”, then click “Ethernet” (May have different names).




B. Go to “Properties” → “Internet Protocol Version 4(TCP/IPv4)” and select “Use the following IP address”, then assign a static IP manually within the same subnet of the gateway.




C. Open a Web browser on your PC (Chrome is recommended) and type in the IP address 192.168.1.1 to access the web GUI.

D. Enter the username and password, click “Login”.




If you enter the username or password incorrectly more than 5 times, the login page will be locked for 10 minutes.

E. When you log in with the default username and password, you will be asked to change password. It’s suggested that you change the password for the sake of security. Click “Cancel” button if you want to modify it later.



F. After you log in the Web GUI, you can view system information and perform configuration of the gateway.




5. Connect UG65 to the Network

This section explains how to connect the gateway to network via WAN connection, Wi-Fi or cellular.


5.1 Configure the WAN Connection

- A. Go to “Network”→ “Interface” → “Port” page to select the connection type and configure Ethernet port information.
- B. Click “Save & Apply” for changes to take effect.



IP Address	Netmask	Operation
		+

- C. Connect Ethernet port of gateway to devices like router or modem.
- D. Log in the web GUI via the newly assigned IP address and go to “Status”→ “Network” to check Ethernet port status.



Port	Status	Type	IP Address	Netmask	Gateway	DNS	Duration
eth 0	up	Static	192.168.23.64	255.255.255.0	192.168.23.1	8.8.8.8	03h 12s

5.2 Configure the Wi-Fi Connection

- A. Go to “Network” → “Interface” → “WLAN” and select “Client” mode.
- B. Click “Scan” to search for Wi-Fi access point. Select the available one and click “Join Network”.

Port	WLAN	Cellular	Loopback				
< GoBack							
SSID	Channel	Signal	Cipher	BSSID	Security	Frequency	
Ursalink_F0DCAF	Auto	-68dBm	Auto	24:e1:24:f0:dc:af	No Encryption	2437MHz	Join Network
Ursalink_F0C422	Auto	-64dBm	Auto	24:e1:24:f0:c4:22	No Encryption	2437MHz	Join Network
Ursalink_F0DE8C	Auto	-66dBm	Auto	24:e1:24:f0:de:8c	No Encryption	2462MHz	Join Network

- C. Type the key of Wi-Fi.

Port	WLAN	Cellular	Loopback
WLAN			
Enable	<input checked="" type="checkbox"/>		
Work Mode	Client		Scan
SSID	Ursalink_Tec		
BSSID	24:e1:24:f0:2c:4b		
Encryption Mode	WPA-PSK/WPA2-PSK		
Cipher	AES		
Key		
IP Setting			
Protocol	DHCP Client		

- D. Go to “Status”→“WLAN” to check Wi-Fi status. If it shows “Connected”, it means gateway connects to Wi-Fi successfully.

Overview	Packet Forward	Cellular	Network	WLAN
WLAN Status				
Wireless Status	Enabled			
MAC Address	24:e1:24:f0:c4:34			
Interface Type	Client			
SSID	Ursalink_Tec			
Channel	Auto			
Encryption Type	WPA-PSK/WPA2-PSK			
Cipher	AES			
Status	Connected			
IP Address	192.168.250.146			
Netmask	255.255.255.0			
Connection Duration	0 days, 00:00:05			

5.3 Configure the Cellular Connection

- A. Go to “Network” → “Interface” → “Cellular” → “Cellular Setting” page to enable cellular settings.
- B. Choose relevant network type and fill in SIM card information like APN or PIN code.
- C. Click “Save” and “Apply” for changes to take effect.

Port	WLAN	Cellular	Loopback
Cellular Setting			
Enable	<input checked="" type="checkbox"/>		
Network Type	Auto ▼		
APN	<input type="text"/>		
Username	<input type="text"/>		
Password	<input type="text"/>		
Access Number	<input type="text"/>		
PIN Code	<input type="text"/>		
Authentication Type	Auto ▼		
Roaming	<input checked="" type="checkbox"/>		
SMS Center	<input type="text"/>		
Connection Setting	<input type="checkbox"/>		
Enable NAT	<input checked="" type="checkbox"/>		

D. Go to “Status” → “Cellular” page to view the status of the cellular connection. If it shows “Connected”, it means the SIM has dialed up successfully. On the other hand, you can check the status of LTE indicator. If it keeps on green light statically, it means SIM has dialed up successfully.

Overview	Packet Forward	Cellular	Network	WLAN
 Modem				
Status		Ready		
Model		EC25		
Version		EC25ECGAR06A07M1G		
Signal Level		23asu (-67dBm)		
Register Status		Registered (Home network)		
IMEI		860425047368939		
IMSI		460019425301842		
ICCID		89860117838009934120		
ISP		CHN-UNICOM		
Network Type		LTE		
PLMN ID				
LAC		5922		
Cell ID		340db83		
 Network				
Status		Connected		
IP Address		10.132.132.59		
Netmask		255.255.255.240		
Gateway		10.132.132.60		

6. Packet Forwarder Configuration

UG65 has embedded multiple packet forwarders like TTN and Chirpstack. This section explains how to connect the gateway to third-party network servers.



Make sure the gateway connects to the network as shown in [Section 5](#).

A. Go to “Packet Forwarder” → “General” page and click to add a network server.

ID	Enable	Type	Server Address	Operation
0	Enabled	Ursalink	localhost	
1	Disabled	TTN	-	
2	Disabled	Semtech	router.cn.thethings.network	

B. Fill in the server information and enable this server.

Note: When you select any of TTN or Chirpstack, other servers are not allow to enable.

Enable
 Type: Semtech
 Server Address: router.eu.thethings.network
 Port Up: 1700
 Port Down: 1700

C. Go to “Packet Forwarder” → “Radio” page to configure antenna transmission type, center frequency and channels. The channels of the gateway and network server need to be the same.

Note: for built-in antenna models, please select “2 × Built-in ANT”; for external antenna models, please select “Ext ANT(TX+RX)+ Built-in ANT(RX)”.

General **Radios** Advanced Custom Traffic

Antenna Type: 2 x Built-in ANT

Radio Channel Setting

Supported Frequency: CN470

Name	Center Frequency/MHz
Radio 0	472.3
Radio 1	472.9

Multi Channels Setting

Enable	Index	Radio	Frequency/MHz
<input checked="" type="checkbox"/>	0	Radio 0	471.9
<input checked="" type="checkbox"/>	1	Radio 0	472.1
<input checked="" type="checkbox"/>	2	Radio 0	472.3
<input checked="" type="checkbox"/>	3	Radio 0	472.5
<input checked="" type="checkbox"/>	4	Radio 1	472.7
<input checked="" type="checkbox"/>	5	Radio 1	472.9
<input checked="" type="checkbox"/>	6	Radio 1	473.1
<input checked="" type="checkbox"/>	7	Radio 1	473.3

D. Add the gateway on network server page. Take TTN for example, type and save the gateway EUI and other information when you connect it via Semtech packet forwarder. After you add the gateway, TTN will show connection status.

Gateways > Register

REGISTER GATEWAY

Gateway EUI
The EUI of the gateway as read from the LoRa module

24 E1 24 FF FE 8 bytes

I'm using the legacy packet forwarder
Select this if you are using the legacy [Semtech packet forwarder](#).

Description
A human-readable description of the gateway

Frequency Plan
The [frequency plan](#) this gateway will use

Australia 915MHz

E. Go to "Traffic" page to view the data communication of UG65.

General Radios Advanced Custom **Traffic**

Traffic Setting

Stop Clear

Rfch	Direction	Time	Ticks	Frequency	Datarate	Coderate	RSSI	SNR
1	up	11:52:38	317882157 1	865.985	SF7BW125	4/5	-91	5.0
1	up	11:52:22	316226269 2	866.585	SF7BW125	4/7	-108	-11.8
0	down	-	311888813 1	865.0625	SF7BW125	4/5	-	-
0	up	11:51:37	311788813 1	865.0625	SF7BW125	4/5	-95	-0.8

7. Network Server Configuration

UG65 can work as network server and transmit data to Ursalink Cloud or other platform via MQTT/HTTP/HTTPS.

! Make sure the gateway connects to the network as shown in [Section 5](#).

7.1 Connect UG65 to Ursalink Cloud

A. Go to “Packet Forwarder” → “General” page to enable the “Ursalink” type server.

ID	Enable	Type	Server Address	Operation
0	Enabled	Ursalink	localhost	[Edit] [Delete] [Add]


B. Go to “Packet Forwarder” → “Radio” page to select the antenna transmission type, center frequency and channels. The channels of the gateway and LoRaWAN nodes need to be the same.

Note: for built-in antenna models, please select “2 × Built-in ANT”; for external antenna models, please select “Ext ANT(TX+RX)+ Built-in ANT(RX)”.


Name	Center Frequency/MHz
Radio 0	472.3
Radio 1	472.9

Enable	Index	Radio	Frequency/MHz
<input checked="" type="checkbox"/>	0	Radio 0	471.9
<input checked="" type="checkbox"/>	1	Radio 0	472.1
<input checked="" type="checkbox"/>	2	Radio 0	472.3
<input checked="" type="checkbox"/>	3	Radio 0	472.5
<input checked="" type="checkbox"/>	4	Radio 1	472.7
<input checked="" type="checkbox"/>	5	Radio 1	472.9
<input checked="" type="checkbox"/>	6	Radio 1	473.1
<input checked="" type="checkbox"/>	7	Radio 1	473.3


C. Go to “Network Server” → “General” page to enable the network server and Ursalink Cloud mode.



D. Register and log in the Ursalink Cloud (cloud.ursalink.com).



E. Go to “Gateway” page and click “Add” to add a gateway.




F. The gateway is online on Ursalink Cloud.




7.2 Connect UG65 to Other Platform

A. Go to “Packet Forwarder” → “General” page to enable the “Ursalink” type server.




B. Go to “Packet Forwarder” → “Radio” page to select the antenna transmission type, center frequency and channels. The channels of the gateway and LoRaWAN nodes need to be the same.

Note: for built-in antenna models, please select “2 × Built-in ANT”; for external antenna models, please select “Ext ANT(TX+RX)+ Built-in ANT(RX)”.




C. Go to “Network Server” → “General” page to enable the network server mode.




The screenshot shows the 'General Setting' page for the Network Server. The 'Enable' checkbox is checked and highlighted with a red box. Other settings include: Ursalink Cloud (unchecked), NetID (010203), Join Delay (5 sec), RX1 Delay (1 sec), Lease Time (876000-0-0 hh-mm-ss), and Log Level (info).

D. Go to “Network Server” → “Application” to add a new application.



The screenshot shows the 'Applications' page. The 'Name' field contains 'cloud', the 'Description' field contains 'cloud', and the 'Payload Codec' dropdown is set to 'None'.

After saving the application, you can select HTTP, HTTPS or MQTT protocol and fill in correspond server information to send data to another server.




The screenshot shows the 'Data Transmission' configuration page. The 'Type' dropdown is set to 'MQTT'. The 'General' section includes fields for Broker Address, Broker Port, Client ID, Connection Timeout/s (30), and Keep Alive Interval/s (60).

E. Go to “Profiles” page to add a new profile for the device.


Name	Max TXPower	Join Type	Class Type	Operation
ClassA-OTAA	0	OTAA	Class A	
ClassC-OTAA	0	OTAA	Class C	

F. Go to “Device” page and click “Add” to add LoRaWAN node devices.

You can also click “Bulk Import” if you want to add many LoRaWAN nodes all at once.




Click “Template Download” to download template file and add LoRaWAN device information to this file. Application and device profile should be the same as you created on web page.



Import this file to add bulks of devices.

G. Go to “Packets” page to check the packets from LoRaWAN node devices. The type starts from “Up” means uplinks and “Dn” means downlinks.



Click “Details” to check the properties and payload contents of packets.

Packets Details	
Fcnt	14
Port	85
Modulation	LORA
Bandwidth	125
SpreadFactor	7
Bitrate	0
CodeRate	4/5
SNR	8.5
RSSI	-85
Power	-
Payload(b64)	A3cYAA==
Payload(hex)	03771800
MIC	f5acdeb2

[END]