



UG85 LoRaWAN Gateway

Quick Start Guide



Welcome

Thank you for choosing Ursalink UG85 LoRaWAN Gateway.

This guide teaches you how to install the UG85 and how to log in the web GUI to configure the device. Once you complete the installation, refer to the Ursalink UG85 User Guide for instructions on how to perform configurations on the device.

Related Documents



This Quick Start Guide only explains the installation of Ursalink UG85 LoRaWAN Gateway. For more functionality and advanced settings, please refer to the relevant documents as below.

Document	Description
Ursalink UG85 Datasheet	Datasheet for the Ursalink UG85 LoRaWAN Gateway.
Ursalink UG85 User Guide	Users can refer to the guide for instruction on how to log in the web GUI, and how to configure all the settings.

The related documents are available on Ursalink website: <http://www.ursalink.com>.

Declaration of Conformity

UG85 is in conformity with the essential requirements and other relevant provisions of the CE, FCC, and RoHS.



For assistance, please contact
Ursalink technical support:
Email: support@ursalink.com
Tel: 86-592-5023060
Fax: 86-592-5023065

Revision History

Date	Doc Version	Firmware	Description
Jun. 14,2019	V1.1	-	Initial version
Apr. 4, 2020	V1.2	80.0.0.62	1. Reset button definition change; 2. Default IP change from 192.168.1.1 to 192.168.23.150; 3. Web GUI interface change; 4. Add bulk import LoRaWAN devices.

Contents


1. Packing List.....	3
2. Hardware Introduction.....	4
2.1 Overview.....	4
2.2 Dimensions.....	4
2.3 Pinouts.....	5
2.4 LED Indicators.....	5
2.5 Reset Button.....	6
3. Hardware Introduction.....	7
3.1 SIM Card Installation.....	7
3.2 Antenna Installation.....	7
3.3 Ethernet Port Connection.....	8
3.4 Mount the gateway.....	8
3.4.1 Wall Mounting.....	8
3.4.2 DIN Rail Mounting.....	8
3.5 Power Supply Installation.....	9
4. Access the Web GUI of UG85.....	10
4.1 PC Configuration.....	10
4.2 Log in the Web GUI of UG85.....	11
5. Connect UG85 to the Network.....	13
5.1 Configure the WAN Connection.....	13
5.2 Configure the Cellular Connection.....	13
5.3 Configure the Wi-Fi Connection.....	15
6. Packet Forwarder Configuration.....	18
7. Network Server Configuration.....	18
7.1 Connect UG85 to Ursalink Cloud.....	20
7.2 Connect UG85 to Other Platform.....	21

1. Packing List


Before you begin to install the UG85 LoRaWAN Gateway, please check the package contents to verify that you have received the items below.



1 × UG85




1 × Ethernet Cable




1 × Power Adapter




1 × Stubby LoRa
Antenna




1 × 6-Pin Pluggable
Terminal



1 × DIN Rail Kit



4 × Setscrews




1 × Warranty Card



1 × GPS Antenna
(GPS Version Only)



1 × Magnetic
Cellular Antenna
(Cellular Version Default)



1 × Stubby Wi-Fi Antenna
(Wi-Fi Version Only)



1 × Stubby
Cellular Antenna
(Cellular Version Optional)




If any of the above items is missing or damaged, please contact your Ursalink sales representative.

2. Hardware Introduction


2.1 Overview

A. Front Panel




- ① WIFI/LTE Antenna
- ② GPS Antenna
- ③ LoRa Antenna
- ④ LED Indicator Area
POWER: Power Indicator
SYSTEM: Status Indicator
LORA: LoRa Indicator
WIFI: WIFI Indicator
LTE: Cellular Status Indicator
LAN: Ethernet Port Status Indicator
- ⑤ Serial Port & I/O
- ⑥ Ethernet WAN/LAN Port
- ⑦ Console Port
- ⑧ Power Connector
- ⑨ SIM and Reset Button Holder


2.2 Dimensions (mm)



2.3 Pinouts



V+ V-



PIN	RS232	DI	DO	Description
1	---	---	OUT	Digital Output
2	---	IN	---	Digital Input
3	GND	---	---	Ground
4	---	COM	COM	Common Ground
5	RXD	---	---	Receive Data
6	TXD	---	---	Transmit Data

PIN	Description
11	Positive
12	Negative

2.4 LED Indicators

LED	Indication	Status	Description
POWER	Power Status	On	The power is switched on
		Off	The power is switched off
SYSTEM	System Status	Green Light	Static: Start-up Blinking slowly: the system is running properly
		Red Light	The system goes wrong
LoRa	LoRa Status	Green Light	Packet Forwarder mode is running well.
		Off	Packet Forwarder mode is running off.
WIFI	WIFI Status	Green Light	WIFI is connected
		Off	WIFI is disconnected
LTE	Cellular Status	Off	SIM1 or SIM2 is registering or fails to register (or there are no SIM cards inserted)
		Green Light	Blinking slowly: SIM1 or SIM2 has been registered and is ready for dial-up
			Blinking rapidly: SIM1 or SIM2 has been registered and is dialing up now
	Static: SIM1 or SIM2 has been registered and dialed up successfully		
LAN	Ethernet Port Status	Off	Disconnected
		Green Light	Blinking: Transmitting data Static: Connected

2.5 Reset Button

Function	Description	
	SYSTEM LED	Action
Reset	Blinking	Press and hold the reset button for more than 5 seconds.
	Static Green → Rapidly Blinking	Release the button and wait.
	Off → Blinking	The gateway is now reset to factory default.


3. Hardware Introduction

Environmental Requirements


- Power Input: 9-48 VDC
- Power Consumption: Typical 3.3W (Max 6.4 W)
- Operating Temperature: -40°C to 70°C (-40°F -158°F)
- Relative Humidity: 0% to 95% (non-condensing) at 25°C/77°F

3.1 SIM Card Installation

A. Unscrew the cover of the SIM card then take it off.





B. Put SIM card into the slot and screw it up.



3.2 Antenna Installation


Rotate the antenna into the antenna connector accordingly.

The external antenna should be installed vertically always on a site with a good cellular signal.



3.3 Ethernet Port Connection

Connect LAN port of UG85 to computer or network devices. Please note that do not connect to console port.





3.4 Mount the gateway

The gateway can be placed on a desktop or mounted to a wall or a DIN rail.

3.4.1 Wall Mounting (Measured in mm)


Use 4 pcs of M3 × 6 flat head Phillips screws to fix the gateway on the wall.


 Recommended torque for mounting is 1.0 N·m, and the maximum allowed is 1.2 N·m.



3.4.2 DIN Rail Mounting (Measured in mm)


Use 2 pieces of M3 × 6 flat head Phillips screws to fix the DIN rail to the gateway, and then hang the DIN rail on the mounting bracket. It is necessary to choose a standard bracket.

 Recommended torque for mounting is 1.0 N·m, and the maximum allowed is 1.2 N·m.



3.5 Power Supply Installation

- A. Take out the terminal from the gateway and unscrew the bolt on terminal.
- B. Screw down the bolt after inserting power cable into the terminal.



Connecting the Power Cable

Color	Polarity
Red	+
Yellow	-

⚠ If you insert wires into the reverse holes, the gateway will not start and you must switch the wires into the correct holes.

4. Access the Web GUI of UG85

Ursalink UG85 provides web-based configuration interface for management. If this is the first time you configure the gateway, please use the default settings below:



IP Address: **192.168.23.150**

Username: **admin**

Password: **password**



4.1 PC Configuration

Please connect PC to LAN port of UG85 directly and configure a static IP address manually. The following steps are based on Windows 10 operating system for your reference.


① Click “Search Box” to search “Control Panel” on the Windows 10 taskbar.

② Click “Control Panel” to open it, and then click “View network status and tasks”.





③ Click “Ethernet” (May have different names).

④ Click “Properties”.



- ⑤ Double Click “Internet Protocol Version 4 (TCP/IPv4)” to configure IP address and DNS server.





- ⑥ Click “Use the following IP address” to assign a static IP manually within the same subnet of the gateway.

(Note: Remember to click “OK” to finish configuration.)

4.2 Log in the Web GUI of UG85

- A. Open a Web browser on your PC (Chrome and IE are recommended), type in the IP address, and press Enter on your keyboard.
- B. Enter the username and password, click “Login”.



⚠ If you enter the username or password incorrectly more than 5 times, the login page will be locked for 10 minutes.

- C. When you log in with the default username and password, you will be asked to change password. It’s suggested that you change the password for the sake of security. Click “Cancel” button if you want to modify it later.

Change Password ✕


Old Password

New Password

Confirm New Password

Save Cancel

D. After you log in the Web GUI, you can view system information and perform configuration of the gateway.

For your device security, please change the default password

Status

LoRaWAN ▶

Network ▶

System ▶

Industrial ▶

Maintenance ▶

APP ▶

OverviewLoRaCellularNetworkVPNHost List

System Information

Model	UG85
Partnumber	L00E-S1011-EU868
Serial Number	621791810162
Firmware Version	80.0.0.6
Hardware Version	V1.0
Local Time	2019-06-11 11:30:26
Uptime	00:15:40
CPU Load	28%
RAM (Capacity/Available)	512MB/257MB(50.2%)
eMMC (Capacity/Available)	6.6G/6.0G(91.63%)


Manual Refresh ▼ Refresh

5. Connect UG85 to the Network

This chapter explains how to connect the gateway to network via WAN connection, cellular or Wi-Fi.

5.1 Configure the WAN Connection

- A. Go to “Network”→ “Interface” → “Port” page to select the connection type and configure WAN information.
- B. Click “Save&Apply” for configuration to take effect.



- C. Connect Ethernet port of gateway to network devices like router or modem.
- D. Log in the web GUI via the newly assigned IP address and go to “Status”→ “Network” to check ethernet port status.





Port	Status	Type	IP Address	Netmask	Gateway	DNS	Duration
GE 0	up	Static	192.168.22.229	255.255.255.0	192.168.22.1	8.8.8.8	03h 01m 21s

5.2 Configure the Cellular Connection

Take inserting SIM card into SIM1 slot as an example; please refer to the following detailed operations.


- A. Go to “Network” → “Interface” → “Cellular” → “Cellular Setting” page to configure the cellular info.

- B. Enable SIM1.
- C. Choose relevant network type. "Auto", "4G Only", "3G Only" and "2G Only" are optional.
- D. Click "Save" and "Apply" for configuration to take effect.



UG85 has two cellular interfaces named SIM1 & SIM2. Only one cellular interface is active at one time. If both cellular interfaces are enabled, SIM1 interface takes precedence by default.

E. Go to “Status” → “Cellular” page to view the status of the cellular connection. If it shows “Connected”, it means SIM1 has dialed up successfully. On the other hand, you can check the status of LTE indicator. If it keeps on green light statically, it means SIM has dialed up successfully.



Status	Overview	LoRa	Cellular	Network	VPN
LoRaWAN	Modem				
	Status		Ready		
Network	Model		EC25		
System	Current SIM		SIM1		
Industrial	Signal Level		31asu (-51dBm)		
Maintenance	Register Status		Registered (Home network)		
APP	IMEI		861107032321490		
	IMSI		460110269496240		
	ICCID		89860317245923922835		
	ISP		CHN-CT		
	Network Type		LTE		
	PLMN ID		46011		
	LAC		5f02		
	Cell ID		5fb0d34		
	Network				
	Status		Connected		
	IP Address		172.21.143.187		
	Netmask		255.255.255.248		
	Gateway		172.21.143.188		
	DNS		218.85.152.99		
	Connection Duration		0 days, 00:01:39		

5.3 Configure the Wi-Fi Connection

- A. Go to “Network” → “Interface” → “WLAN” and select “Client” mode.
- B. Click “Scan” to search for Wi-Fi access point. Select the available one and click “Join Network”.

Port	WLAN	Cellular	Loopback				
< GoBack							
SSID	Channel	Signal	Cipher	BSSID	Security	Frequency	
Ursalink_F08A9B	Auto	-76dBm	Auto	24:e1:24:f0:8a:9b	No Encryption	2412MHz	Join Network
Ursalink_F03D6D	Auto	-75dBm	Auto	24:e1:24:f0:3d:6d	No Encryption	2412MHz	Join Network
Ursalink_EEFF89	Auto	-73dBm	Auto	24:cc:dd:ee:ff:89	No Encryption	2412MHz	Join Network
+4413133	Auto	-77dBm	AES	24:e1:24:f0:32:1b	WPA-PSK/WPA2-PSK	2412MHz	Join Network
AABB	Auto	-75dBm	AES	24:e1:24:f0:32:1b	WPA-PSK/WPA2-PSK	2412MHz	Join Network
Redmi	Auto	-75dBm	AES	2a:56:e4:fe:2b:b2	WPA2-PSK	2412MHz	Join Network
Ursalink_Tec	Auto	-73dBm	AES	24:e1:24:f0:2c:4b	WPA-PSK/WPA2-PSK	2452MHz	Join Network

C. Type the correct key of Wi-Fi.

Port	WLAN	Cellular	Loopback
WLAN			
Enable	<input checked="" type="checkbox"/>		
Work Mode	Client		Scan
SSID	Ursalink_TechnologyCenter		
BSSID	24:e1:24:f0:01:1a		
Encryption Mode	WPA-PSK/WPA2-PSK		
Cipher	AES		
Key		
IP Setting			
Protocol	DHCP Client		


D. Go to “Status”→”WLAN” to check Wi-Fi status. If it shows “Connected”, it means gateway connects to Wi-Fi successfully.


Overview	Packet Forward	Cellular	Network	<u>WLAN</u>
 WLAN Status				
Wireless Status	Enabled			
MAC Address	24:e1:24:f0:27:d6			
Interface Type	Client			
SSID	Ursalink_TechnologyCenter			
Channel	Auto			
Encryption Type	WPA-PSK/WPA2-PSK			
Cipher	AES			
Status	Connected			
IP Address	0.0.0.0			
Netmask	0.0.0.0			
Connection Duration	0 days, 00:00:01			

6. Packet Forwarder Configuration

UG85 has embedded multiple packet forwarders like TTN, Loriot and chirpstack. This chapter explains how to connect the gateway to third-party network servers.

 **Make sure the gateway connects to the network as shown in [Chapter 5](#).**







A. Go to “Packet Forwarder” → “General” page and click  to add a network server.



The screenshot shows the 'General Setting' page for Packet Forwarder configuration. The left sidebar contains navigation options: Status, Packet Forwarder (selected), Network Server, Network, System, Maintenance, and APP. The main content area has tabs for General, Radios, Advanced, Custom, and Traffic. Under 'General Setting', the following fields are visible:

- Gateway EUI: 24E124FFFF
- Gateway ID: 24E124FFFF
- Frequency-Sync: Disabled


Below these is a 'Multi-Destination' table:

ID	Enable	Type	Server Address	Operation
0	Enabled	Ursalink	localhost	 
1	Disabled	TTN	-	 
2	Disabled	Semtech	router.cn.thethings.net work	 

A plus icon is located at the bottom right of the table to add a new server.

B. Fill in the server information and enable this server.

Note: When you select one of TTN, Loriot or chirpstack, other servers are not allow to enable.



The modal dialog for adding a server contains the following fields:

- Enable:
- Type: Semtech (dropdown)
- Server Address: router.eu.thethings.network (dropdown)
- Port Up: 1700
- Port Down: 1700

A 'Save' button is located at the bottom center of the dialog.

C. Go to “Radios” page to configure the center frequency and channels.

Note: the channel plan of the gateway and network server need to be the same.

General **Radios** Advanced Custom Traffic

Radio Channel Setting

Supported Frequency: AU915

Name	Center Frequency/MHz
Radio 0	917.0
Radio 1	917.8

Multi Channels Setting

Enable	Index	Radio	Frequency/MHz
<input checked="" type="checkbox"/>	0	Radio 0	916.8
<input checked="" type="checkbox"/>	1	Radio 0	917.0
<input checked="" type="checkbox"/>	2	Radio 0	917.2
<input checked="" type="checkbox"/>	3	Radio 0	917.4
<input checked="" type="checkbox"/>	4	Radio 1	917.6
<input checked="" type="checkbox"/>	5	Radio 1	917.8
<input checked="" type="checkbox"/>	6	Radio 1	918.0
<input checked="" type="checkbox"/>	7	Radio 1	918.2

D. Add the gateway in network server page. Take TTN for example, type and save the gateway EUI and other information when you connect via Semtech packet forwarder. After you add the gateway, TTN will show connection status.

Gateways > Register

REGISTER GATEWAY

Gateway EUI
The EUI of the gateway as read from the LoRa module

24 E1 24 FF FE [] [] [] [] 8 bytes

I'm using the legacy packet forwarder
Select this if you are using the legacy [Semtech packet forwarder](#).

Description
A human-readable description of the gateway

Frequency Plan
The [frequency plan](#) this gateway will use

Australia 915MHz

E. Go to "Traffic" page to view the data communication of UG85.

admin

General Radios Advanced Custom **Traffic**

Traffic Setting

Stop Clear

Rfch	Direction	Time	Ticks	Frequency	Datarate	Coderate	RSSI	SNR
1	up	-	2422567628	922.6	SF7BW125	4/7	-86	-11.5
1	up	-	2027425380	923.0	SF7BW125	4/6	-87	-10.8
1	up	-	1906152459	922.2	SF7BW125	OFF	-89	-11.8
0	up	-	1896642603	923.6	SF7BW125	4/6	-89	-12.0
0	up	-	1833066556	923.8	SF7BW250	4/5	-86	-12.0
0	up	-	1793222443	923.4	SF7BW125	4/8	-85	-11.2
0	up	-	1768923067	923.2	SF7BW125	4/5	-89	-11.8
1	up	-	1736475188	922.8	SF8BW125	4/8	-86	-14.0
1	up	-	1504937860	923.0	SF7BW125	4/5	-87	-11.5


7. Network Server Configuration

UG85 can work as network server and transmit data to Ursalink Cloud or other platform via MQTT/HTTP/HTTPS.

! Make sure the gateway connects to the network as shown in [Chapter 5](#).

7.1 Connect UG85 to Ursalink Cloud

A. Go to “Packet Forwarder” → “General” page to enable the “Ursalink” type server.




ID	Enable	Type	Server Address	Operation
0	Enabled	Ursalink	localhost	


B. Go to “Network Server” → “General” page to enable the network server and Ursalink Cloud mode.



C. Register and log in the Ursalink Cloud (cloud.ursalink.com).



D. Go to “Gateway” page and click “Add” to add a gateway.



E. The gateway is online on Ursalink Cloud.



7.2 Connect UG85 to Other Platform

A. Go to “Packet Forwarder” → “General” page to enable the “Ursalink” type server.

General Setting

Gateway EUI: 24E124FF...
 Gateway ID: 24E124FF...
 Frequency-Sync: Disabled

Multi-Destination

ID	Enable	Type	Server Address	Operation
0	<input checked="" type="checkbox"/>	Ursalink	localhost	✎ ✕
+				

[Save & Apply](#)

B. Go to “Radios” page to configure the center frequency and channels.

Note: the channel plan of the nodes and gateway need to be the same.

Radio Channel Setting

Supported Frequency: AU915

Name	Center Frequency/MHz
Radio 0	917.0
Radio 1	917.8

Multi Channels Setting

Enable	Index	Radio	Frequency/MHz
<input checked="" type="checkbox"/>	0	Radio 0	916.8
<input checked="" type="checkbox"/>	1	Radio 0	917.0
<input checked="" type="checkbox"/>	2	Radio 0	917.2
<input checked="" type="checkbox"/>	3	Radio 0	917.4
<input checked="" type="checkbox"/>	4	Radio 1	917.6
<input checked="" type="checkbox"/>	5	Radio 1	917.8
<input checked="" type="checkbox"/>	6	Radio 1	918.0
<input checked="" type="checkbox"/>	7	Radio 1	918.2

C. Go to “Network Server” → “General” page to enable the network server mode.

General Setting

Enable

Ursalink Cloud:

NetID: 010203


Join Delay: 5 sec

RX1 Delay: 1 sec

Lease Time: 876000-0-0 hh-mm-ss


Log Level: info

D. Go to “Network Server”→”Application” to add a new application.




The screenshot shows the 'Applications' tab selected in the configuration interface. On the left sidebar, 'Network Server' is highlighted. The main content area is titled 'Applications' and contains three input fields: 'Name' with the value 'cloud', 'Description' with the value 'cloud', and 'Payload Codec' with a dropdown menu set to 'None'.

After saving the application, select HTTP, HTTPS or MQTT protocol and fill in correspond server information to send data to another server.



The screenshot shows the 'Data Transmission' configuration section. The 'Type' dropdown menu is open, showing options for HTTP, MQTT (which is highlighted), and HTTPS. Below this, the 'General' section contains several input fields: 'Broker Address', 'Broker Port', 'Client ID', 'Connection Timeout/s' (set to 30), and 'Keep Alive Interval/s' (set to 60).

E. Go to “Profiles” page to add a new profile for the device.



The screenshot shows the 'Device Profiles' configuration page with the 'Profiles' tab selected. The 'Device Profiles' section contains the following fields: 'Name' (ClassA-OTAA), 'Max TXPower' (0), 'Join Type' (OTAA), and 'Class Type' (Class A). There is an 'Advanced' checkbox which is currently unchecked. At the bottom, there are 'Save' and 'Cancel' buttons.

General		Applications		Profiles		Device		Packets	
Device Profiles									
Name	Max TXPower	Join Type	Class Type	Operation					
ClassA-OTAA	0	OTAA	Class A	✎ ✕					
ClassC-OTAA	0	OTAA	Class C	✎ ✕					
+									

F. Go to “Device” page and click “Add” to add LoRaWAN node devices.

General		Applications		Profiles		Device		Packets	
Device									
Add		Bulk Import		Delete All		Search <input type="text"/>			
Device Name	Device EUI	Device-Profile	Application	Last Seen	Activated	Operation			
No matching records found									

Device Name

Description

Device EUI

Device-Profile

Application

Frame-counter Validation

Application Key

Device Address

Network Session Key

Application Session Key

Uplink Frame-counter

Downlink Frame-counter


Save & Apply

You can also click “Bulk Import” if many LoRaWAN nodes need to add.

Import File


Browse **Import** **Template Download**

Click “Template Download” to download template file and add LoRaWAN device information to this file. Application and deviceprofile should be the same as you created in web page.




Import this file to add bulks of devices.

G. Go to “Packets” page to check the packets from LoRaWAN node devices. The type starts from “Up” means uplinks and “Dn” means downlinks.



Click “Details” to check the properties and payload contents of packets.



[END]